

For installation in raised wooden floor where backbox is not required.

- 1) Print this file with "Page Scaling" set to "None".
- 2) Check for proper scale by measuring lines at bottom right of page.
- 3) Adjust printer settings if necessary until both lines equal 2".
- 4) Cut opening $4 \frac{7}{8}$ " x $4 \frac{3}{4}$ ", taking note of the proper hinge orientation.
- 5) Install FMCA using backing strips per TechNote TN13.

FMCA hinge will mount on this side

