



FMCA Series 2000 Cutout Template

For installation in raised wooden floor where backbox is not required.

Please check for proper scale by measuring perpendicular lines below. If lines are not equal to one inch, reset printer settings until they are.

